GUARDMAX

Telescopic Platform Ladder

User Guide

SETTING UP



Release transport catch



Stand ladder upright



Open ladder out



Ensure deck rests on top rear rung



Loosen clamps and slide out stabilisers on all 4 stiles



with stabiliser feet in contact with the ground



Unlock the gate and climb onto the platform



Close gate and engage latch

ADJUSTING THE PLATFORM HEIGHT



Unlock ladder interlock clip



Push ladder up one rung and lock interlock clip



Repeat on opposite side. Repeat process until desired platform height is reached



SAFE USE



Read the instructions



Visually check before use



Fully open ladder and stabilisers before use



Keep a secure grip



= Max. 110Kg (SWL) Duty rating



Ensure firm and level ground



Do not step off side of ladder



1 person only



Avoid over reaching



Avoid electrical hazards



OEnsure ground is free from contaminents



damaged equipment